



PACKAGING CONTENTS

The following items are included in your package. If you find anything missing, contact your system administrator.




ASSEMBLING THE PHONE

1. Attach the stand, as shown below:




2. Connect the handset and optional headset, as shown below:



Note: The headset and wireless headset adapter EHS36 are purchased separately. The EXT port can also be used to connect an EXP40 Sidecar module. For more information on how to use EHS36 or EXP40 Sidecar, refer to the Yealink EHS36 User Guide or Commander EXP40 Sidecar User Guide.

3. Connect the network and power, as shown below:
 You have two options for network and power connections.



Note: If power is provided over Ethernet (PoE) do not connect the power adapter. Make sure the Ethernet cable and switch are PoE-compliant. The phone can also share the network with another network device such as a PC (personal computer). It is an optional connection. **Important!** Do not unplug or remove power to the phone while it is updating firmware and configurations.

STARTUP

After the IP phone is connected to the network and supplied with power, it automatically begins with the initialisation process.

Please allow up to 10 minutes for the phone to connect to Commander’s servers to collect their configuration and any required updates. The phone may reboot two or three times during this process or after factory default setting is made. The display will indicate the current status of the operation with ‘initialising’ and ‘configuration updating’. After startup, the phone is ready for use.

If you require assistance, please call the Commander Phone team on 1300 638 208, or email us at commanderphone@commander.com.